



# Ulefone Phone Paris Disassembly

How to disassemble the Paris Ulefone Switch TouchScreen in the Ulefone Paris

Written By: rafaelamms



## INTRODUCTION

This guide helps with some hardware-level repairs on this equipment, as in this example to change the display

## Step 1 — Open Back Cover



- Open the back cover, through the slot on the left side as shown in the image

## Step 2



- Removing screws only a few pointers and indications may be helpful:
  - Attention this screw marked in red is slightly larger than the others.
  - The green ones are only needed if you need to repair the usb card, speaker

Para remontagem de seu dispositivo, siga estas instruções na ordem inversa.

This document was last generated on 2017-07-15 12:30:49 PM.